

# PurgeEye 200

## Portable O2 Oxygen Trace Detector

The Purgeye 200 is a monitor for detecting traces of oxygen. Using the principle of the zircon probe, it is the first rechargeable and portable oxygen monitor, able to accurately measure an oxygen level ranging from 1 to 1000 ppm (accurate from 10 ppm).



Zirconium

- ✓ Rental from one day
- ✓ Technical assistance included

### TECHNICAL SPECIFICATIONS

MEASURING RANGE: FROM 0 TO 1000 PPM

LONG LIFE ZIRCONIA SENSOR

INTERNAL ELECTRO-MECHANICAL PUMP WITH 1 L/M FLOW RATE

TWO WARNING ALARM LEVELS BETWEEN 10 PPM AND 999 PPM, WITH SETTABLE THRESHOLD LEVELS. ALARM MUTE WHERE DESIRED

ALARM (+) AND (-) BUTTONS FOR DISPLAYING THRESHOLD

MULTI-FUNCTION PUSH BUTTON (STANDBY, MUTE AND PUMP)

AUTOMATIC OFF AFTER 15 MINUTES, AUTOMATIC SLEEP MODE WHEN NOT IN USE

RECHARGEABLE BATTERY OPERATED

LARGE CHARACTER LCD SCREEN FOR EASY READING EVEN AT 10 METERS

QUICK CONNECT / DISCONNECT GAS HOSE CONNECTIONS

IP65 STANDARD, WATERPROOF AND DUSTPROOF

WEIGHT : 400 g

DIMENSIONS : 26 x 12 x 6 cm

### KEY POINTS

- Easy-to-use portable instrument
- Long life zircon sensor
- Quick response
- Easy to read (LCD screen)
- Waterproof (IP65) and dustproof

### APPLICATIONS

- Gas purity measurement
- Leak detection
- Welding processes

### Similar products available at CleanAir:



### For more information

www.cleanaireurope.com  
cleanair.europe@cleanair.com  
+33 4 91 87 82 10