

Self-Regulating Heated Line

Gas Sampling line

The self-regulating heated sample lines keep the collected gas sample above its dew point to prevent condensation and prevent trapping of soluble compounds. They can be regulated up to 180°C. Several dimensions are available according to your applications and needs.



Gas Sampling line

- ✓ Rental from one day
- ✓ Technical assistance included

TECHNICAL SPECIFICATIONS

MAX. OPERATING T°	200 °C
AMBIENT T°	+ 20 to +65 °C
IP PROTECTION	IP64 (EN60529)
POWER	90 W / meter
VOLTAGE	230 VAC 50 Hz (115 VAC 60 Hz optional)
CAP	PTFE
LENGTHS	- 1 m - 5 m - 3 m - 7,5 m - 15 m - 20 m - 30 m

KEY POINTS

- Robust
- Fixed resistance heating cable
- Self regulated Temperature up to 200°C

APPLICATIONS

- Industrial Emissions Analysis
- Industrial processes
- Laboratories
- Research & development

Related products available at CleanAir:



For more information

www.cleanaireurope.com
cleanair.europe@cleanair.com
+33 4 91 87 82 10